

シャープナー対応型番

○ 対応 / × 使用不可

	 GSS-01	 GSS-02	 GSS-03	 GSS-04
GS-3	○	○	×	○
GS-5	○	○	×	○
GS-10	×	×	×	×
GS-11	○	○	×	○
GS-38	○	○	×	○
GS-58	○	○	×	○
GS-61	×	×	×	×
G-2	○	○	×	○
G-3	○	○	×	○
G-4	○	○	×	○
G-5	○	○	×	○
G-9	×	×	×	×
G-46	○	○	×	○
G-55	○	○	×	○
G-57	○	○	×	○
IST-01	×	×	○	○
IST-02	×	×	○	○
IST-03	×	×	○	○
IST-04	×	×	×	×
IST-05	×	×	×	×
IST-06	×	×	×	×